

# HONDA SWRA (Honda Jazz, Fit)

## CONSTANTLY VARIABLE FWD (Electronic Control)




AUTOMATIC CHOICE



THE AUTOMATIC TRANSMISSION PARTS WAREHOUSE

A



# HONDA SWRA (Honda Jazz, Fit)

## CONSTANTLY VARIABLE FWD (Electronic Control)




AUTOMATIC CHOICE



THE AUTOMATIC TRANSMISSION PARTS WAREHOUSE

B



# HONDA SWRA (Honda Jazz, Fit,)

## CONSTANTLY VARIABLE FWD (Electronic Control)



AUTOMATIC CHOICE



THE AUTOMATIC TRANSMISSION PARTS WAREHOUSE

ILL NO.	DESCRIPTION	YEARS	QTY	PART NO
<b>KITS</b>				
Kit	Overhaul Kit (Transtec) (Jazz/City Models) .....	02-ON	1	ECVT.OHK05
Kit	Gasket & Seal Kit.....	02-ON	1	ECVT.OHK04
<b>GASKETS</b>				
100A	Solenoid Block Gasket.....	02-ON	1	ECVT.GAS12
101A	Intermediate Plate Gasket .....	02-ON	1	ECVT.GAS10
102A	Main Case Gasket .....	02-ON	1	ECVT.GAS09
103A	End Cover Gasket.....	02-ON	1	ECVT.GAS11
<b>RUBBER COMPONENTS</b>				
125A	'O' Ring Primary Shaft (29.50mm x 1.90mm).....	02-ON	3	ECVT.OR07
132B	'O' Ring End Cover Feed Tube (30.90mm x 1.90mm).....	02-ON	2	ECVT.OR05
133B	'O' Ring End Cover Feed Tube (11.00mm x 1.90mm).....	02-ON	2	ECVT.OR06
<b>METAL CLAD SEALS</b>				
150A	Manual Shaft.....	02-ON	1	ECVT.MCS11
151A	Drive Shaft Left Hand (35mm x 36mm x 8mm) .....	02-ON	1	ECVT.MCS08
152A	Drive Shaft Right Hand.....	02-ON	1	HON4.MCS10
153A	Input Seal.....	02-ON	1	ECVT.MCS10
<b>MOULDED PISTONS</b>				
<b>SEALING RINGS</b>				
200A	Secondary Drive Gear .....	02-ON	1	ECVT.SSR01
<b>FRICTION PLATES</b>				
<b>STEEL PLATES</b>				
<b>PRESSURE PLATES</b>				
<b>SPRINGS &amp; CIRCLIPS</b>				

ILL NO.	DESCRIPTION	YEARS	QTY	PART NO
<b>FILTERS</b>				
450B	Internal Filter .....	02-ON	1	ECVT.FIL08
<b>BANDS</b>				
<b>BUSHINGS</b>				
<b>THRUST WASHERS &amp; BEARINGS</b>				
<b>ELECTRICAL COMPONENTS</b>				
<b>VALVE BODY PARTS</b>				
<b>HARD PARTS</b>				
<b>SPECIAL ITEMS</b>				
<b>TOOLS &amp; MANUALS</b>				